

PAIRING THE DELL BLUETOOTH KEYBOARD AND MOUSE

1. Insert the batteries into the keyboard. The battery bay is located underneath the keyboard. The keyboard requires two AA batteries.



2. Place the batteries in the mouse. The battery bay is located underneath the mouse. The mouse requires two AA batteries.



PAIRING THE DELL BLUETOOTH KEYBOARD AND MOUSE

3. Turn on the keyboard and mouse using the power switch that is on the bottom of each device.



4. Press the connect button on the bottom of the keyboard. The Bluetooth LED on the top of the keyboard starts to blink.

NOTE: Once you turn the computer on, there is little time to press the connect button on the bottom of the keyboard. Be sure to place the keyboard in discovery mode before turning the computer on.

PAIRING THE DELL BLUETOOTH KEYBOARD AND MOUSE



5. Turn on the computer by pressing the power button.



6. Press the connection button on the USB receiver. When the connection is made, the Bluetooth LED on the keyboard stops blinking and stays steadily on for a few moments, indicating the connection between the keyboard and the computer has been established. The Bluetooth LED on the keyboard then turns off and remains off.

PAIRING THE DELL BLUETOOTH KEYBOARD AND MOUSE



Connect button

7. Press the connection button on the bottom of the mouse. The Bluetooth LED on the top of the mouse starts to blink.



Connect Button

8. Press the connection button on the USB receiver. When the connection is made, the Bluetooth LED on the mouse stops blinking and stays steadily on for a few moments, indicating the connection between the mouse and the computer has been established. The Bluetooth LED



Connect button

on the mouse then turns off and remains off.

9. The Dell Bluetooth Keyboard and Mouse are now ready to use. The next time that you restart the computer, the keyboard, and mouse connect automatically.